


Spring 3

SB-3

Economy Spring Back banner stands incorporate basic design features, functionality and reliability. Economy banners include a basic carry bag and a 90-day hardware warranty.



features and benefits:

- #3 grommets in corners
- single or double sided
- basic carry bag included
- 90 day warranty against all manufacturer defects

dimensions:

| Hardware | Graphic |
|--|--|
| Assembled unit single sided: 29.5"w x 73"h x 9.5"d 749mm(w) x 1854.2mm(h) x 241.3mm(d) | Graphic size: 27.5"w x 70.75"h 698.5mm(w) x 1797.05mm(h) |
| Assembled unit double sided: 29.5"w x 73"h x 19"d 749mm(w) x 1854.2mm(h) x 482.6mm(d) | Refer to related graphic template for more information |
| Shipping | |
| Shipping dimensions: 14"w x 9"h x 5"d 356mm(w) x 228.6mm(h) x 127mm(d) | |
| Shipping weight: 4 lbs / 1.8 kg | |

additional information:


Graphic material:
14 oz anti-curl vinyl



Video


We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

SETUP



Remove the product from the outer packaging and bag.

1




Insert four poles into holes in the hub. Make sure the poles are in all four arms of hub and through the holes opposite from the side with the thumb screw.

2



Insert the leg into the hub. Tighten the thumb screw to secure the leg.

3




Bend top poles so the hooks fit into top grommets. Make sure the hooks fit securely through the grommets.

4



For double sided unit, repeat steps 2-4. The center hub should look like the image above.

5



6