



exhibitline

ex1.enc backwall assembly instructions


Step 1. Attach left and right canopy using 6 **short** knobs and aluminum joining plate.




Steps 2-4. Flip canopy over and attach left and right upper column sections using 2 **short** knobs per column. Install gusset caps. Attach header grippers.



Steps 5,6. Attach left and right lower columns to feet using 2 **short** knobs per column. Install gusset caps.




Steps 7,8. Tip canopy and legs down; attach left and right lower columns to upper columns using 2 **short** thumb knobs per column.




Step 9. Lift canopy into position. Attach graphic panels using 2 **short** nylon tipped knobs per panel.



Step 10. Connect upper and lower graphic hangers. Slide upper and lower graphic hangers into graphic and hang graphic. Use metal slides to apply slight downward pressure on lower graphic hanger.



Step 11. Attach counter legs to counters using 2 **long** knobs for each leg.




Step 12. Attach counters to backwall from underneath using one **long** knob for each counter. Attach shelf using 3 **long** knobs per shelf.



Step 13. Insert panels.





- A. Left canopy
- B. Right Canopy
- C. Plex panels x3
- D. Lower columns x2
- E. Upper columns x2
- F. Header Grippers x2
- G. Canopy Joining Plate
- H. Nylon Tipped Knobs x6
- I. Feet x2
- J. Long Knobs x16
- K. Power Supply
- L. Graphic supports x4
- M. Short Knobs x18
- N. Counter Legs x4
- O. Counters x2
- P. Plastic gusset caps x8
- Q. Folded Graphic
- R. Shelves x2
- S. Left Side Panel x2
- T. Front Panel x2
- U. Right Side Panel x2

