

Lumina 2

LUM-2-1

Lighting can create a powerful, impactful presence or display. Illumination is an important piece of the puzzle to achieve the mood, style and staging that you desire.



Optional Lumina case: SPT-CASE

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

features and benefits:

- Brushed stainless steel finish
- Overhead 50 watt low voltage light with quarter circle stem, 2.5m of cable and AMP connector
- UL approved
- Integral bulldog clip for mounting to pole
- Optional Lumina SPT foam lined case with padded compartments available; holds 2 Lumina lights & power supply.
- One year warranty against manufacturer defects

dimensions:

Hardware	Safety
Assembled unit: 12"	Read all instructions WARNING! To reduce the risk of fire, electric shock or injury to persons:
Weight (includes cables & transformer): .88 lbs / 0.4 kg approx	- Input: 120V, 60Hz - Output: 12V, 60W max - CAUTION: Risk of fire - Use 120 watt or smaller double ended halogen lamp type T-3, 110 volt - CAUTION: To reduce risk of a burn during replacing bulb, disconnect power to the unit by unplugging before bulb replacement.
Shipping	- Keep fixture away from combustible materials - Replace cracked protective shield immediately. Do not use fixture without the shield being installed.
Shipping dimensions - packed in a box: 24"l x 6"w x 6"h 610mm(l) x 152mm(w) x 152mm(h)	- To reduce the risk of exposure to excessive UV radiation, do not remain under light if skin feels warm.
Approximate shipping weight: 2 lbs / 0.9 kg	- Protect the fixture from impact, scratching or abrasions. - If the cord-set becomes damaged, replace the cord-set before using fixture.

additional information:

To Remove Lamp: Turn off/unplug fixture and allow to cool before replacing lamp. Bulb gets hot quickly. Do not touch hot bulb or shade. Remove the protective shield. Push the lamp towards one end of the lamp-holder which serves as a spring to hold lamp in place. When the other end of the lamp is clear of the holder, lift lamp out of fixture.

To Fit or Replace Lamp: Take the bulb out of the box taking care not to touch the bulb with your bare fingers. Oil from skin can damage lamp. Use a soft cloth when grasping lamp. Place one end of the bulb against the spring section of the lamp holder. Bulb is spring loaded on both ends. Push one end in and gently slide other end into place. Reinstall protective shield after changing lamp.