


Mamba Banner - Instructions



Step 1

Open the base, rods and banner from the bag.



Step 2

Insert the top rod into the sleeve on the top of the banner.



Step 3

Start inserting the first (thinnest) rod into the side of the banners, and then adding the next size. Continue to add the metal rods until the top rod has been pushed all the way to the end of the sleeve.

Tip: It is important to ensure the rods are positioned right to the end of the sleeve.



Step 4

Connect the top horizontal rod to the thinnest rod of the side.



Step 5

Bring the bungee string through the grommets on the bottom of the sleeves. Bring it down and adjust the attention of the banner. Secure the metal spring clip on the bottom of the banner to the movable anchor point on the bottom rod. Tie string around the clip to secure the banner.

Tip: If the banner is too loose or too tight, adjust the anchor point up or down accordingly.

Mamba Banner Base



Spike Base

Tap longer pole into the ground. Be careful not to tap & damage the shorter-thicker swivel spindle. Insert the bottom of the pole of the banner into the shorter-thicker swivel spindle.



Cross Base

The collapsible hard ground cross base weighs about 3 kg and is great for use indoor and outdoor.



Water Bag for Cross Base

To give added stability outdoors a water bag is included with each purchase of the cross base. The water bag weighs up to about 18 lbs (9 kg) when full and we highly recommend its use outdoors.



Water Base

Option base fills with water to have additional weight. Weight: 27 lbs (about 3 gallons of water)